

Senseez VIBE Unit - User Guide



SENSEEZ®

Relax | Soothe | Focus



Rechargeable Multi-Speed VIBE – USB

1. This unit does not require batteries
2. It charges only by USB cable (included)
3. The unit comes 20% charged upon receipt
4. To charge the unit, insert the charging jack into the bottom of the vibe unit, and the USB end into a computer or other USB charging source
5. A red light will illuminate when charging. Charge for 4 hours
6. The charge lasts approximately 10-20 hours depending on low, medium or high usage
7. To use the variable speeds, locate the switch at the bottom of the vi be (next to the charging jack) and slide left for low, middle for medium, and right for high. This will vary the intensity of the vibrations
8. This VIBE Unit is not waterproof and should not be in contact with water